


KLUDI BINGO STAR



A_4202378

42023	Waschtisch-Einhandmischer DN 10	single lever basin mixer DN 10	ééngreeps wastafelmengkraan 3/8"
	73 038 Hebel, KLUDI BINGO STAR	lever, KLUDI BINGO STAR	hendel, KLUDI BINGO STAR
	73 053 Auslauf, komplett	spout	uitloop
	74 266 PCA Cache-Luftsprudler M 16,5 x 1	PCA Cache aerator M 16,5 x 1	PCA Cache-perlator M 16,5 x 1
	74 286 Zugstange	lift rod	trekstang
	74 464 Befestigungssatz	assembling set	bevestigingsset
	75 605 Kartusche	cartridge	cartouche
	76 545 Ablaufgarnitur	pop up waste	afvoergarnituur
	823 115 Spannschraube	screw	spanschroef
	922 046 Gewindestift	threading lathe	inbus schroef
	929 077 Armaturenschlüssel	fastening tool	sleutel
	930 186 Abdeckkappe	cover cap	afdekkap
	930 693 Schlüssel für Strahlregler	key for aerator	sleutel voor straalbreker
	930 897 Markierungsstopfen	red/blue insert	markeringsstop